

EMBRAGUE

			No.	PAR
	{rokbox}images/stories/Motor_parts/015_motor.jpg{/rokbox}			
1	196MR-1010000	CLUTCH OUTER		EXTERIOR EMBRAGUE
2	196MR-1000010	COLLAR		COLLARÍN
3	196MR-1000012	CLUTCH CENTER		CENTRO EMBRAGUE
4	196MR-1000100	FRICITION DISK SET		SET DISCO DE FRICCIÓN
5	196MR-1000300	BEARING SET		SET RODAMIENTO
6	196MR-1000001	STEEL DISK SET		SET DE SEPARADORES
7	196MR-1000002	PLATE		PLACA
8	196MR-1000003	CLUTCH LIFTER PIN		PERNO EMBRAGUE
9	196MR-1000007	SPRING		RESORTE
10	196MR-1000008	CLUTCH LIFTER ROD		EJE EMBRAGUE

11	196MR-1000200	BOLT	TORNILLO
12	196MR-1000004	NUT	TUERCA
13	196MR-1000009	WASHER	ARANDELA
14	196MR-1000005	WASHER	ARANDELA
15	196MR-1000006	WASHER	ARANDELA
16	GB 4605-84	WASHER	ARANDELA
17	GB 4605-84	BEARING	RODAMIENTO
18	196MR-1000000	CLUTCH ASSY	EMBLAGUE COMPLETO

□